

A GUIDE TO GEAR RATIO'S

1	13 - 50	3.846
2	13 - 49	3.769
3	13 - 48	3.692
4	13 - 47	3.615
5	13 - 46	3.538
6	14 - 49	3.500
7	13 - 45	3.461
8	14 - 48	3.428
9	13 - 44	3.384
10	14 - 47	3.357
11	13 - 43	3.307
12	14 - 46	3.285
13	15 - 49	3.266
14	13 - 42	3.230
15	14 - 45	3.214
16	15 - 48	3.200
17	13 - 41	3.153
18	14 - 44	3.142
19	15 - 47	3.133
20	16 - 50	3.125
21	13 - 40	3.076

22	14 - 43	3.071
23	15 - 46	3.066
24	16 - 49	3.062
25	14 - 42	3.000
26	15 - 45	3.000
27	16 - 48	3.000
28	16 - 47	2.937
29	15 - 44	2.933
30	14 - 41	2.928
31	16 - 46	2.875
32	15 - 43	2.866
33	14 - 40	2.857
34	16 - 45	2.812
35	15 - 42	2.800
36	16 - 44	2.750
37	15 - 41	2.733
38	16 - 43	2.687
39	15 - 40	2.660
40	16 - 42	2.635
41	16 - 41	2.562
42	16 - 40	2.500

IF A GEAR RATIO IS NOT SHOWN ABOVE THEN USE THE FOLLOWING

DIVIDE THE BACK SPROCKET BY THE FRONT

FOR EXAMPLE "48/16 =3.00

13 FRONT

14 FRONT

15 FRONT

16 FRONT



admin@shortcircuitridersassociation.com

www.shortcircuitridersassociation.com

www.irishclubmanracing.com